



APPLICATION FOR PERMIT:
REPLACEMENT OF EXISTING INDIVIDUAL SEWAGE DISPOSAL SYSTEM

COMPLETE AND RETURN THIS FORM WITH ATTACHED FEE SCHEDULE AND PAYMENT.

REPLACE/UPGRADE <u>TANK ONLY</u> <input type="checkbox"/>

APPLICANT

Name: _____

Home Address: _____

Mailing Address (if different): _____

Home/Cell Phone: _____ Work Phone: _____

Location of Property where work is to be performed:
 _____ T/ _____

SYSTEM INFORMATION (EXISTING)

Septic tank of _____ gallon capacity Clothes Washer

Total Linear Feet of Leach _____ Dishwasher

No. of Existing Bedrooms _____ Garbage Disposal

Year of Installation _____ Hot Tub

Distance from well _____ feet Dug Drilled

Public Water Supply

SEPTIC SYSTEM CONTRACTOR: _____

ADDRESS: _____

CONTACT #s: _____

SIGNATURE OF PROPERTY OWNER

FOR OFFICE USE ONLY ----- PROPOSED UPGRADES

REPLACING EXISTING SEPTIC TANK: YES NO

ADDING ADDITIONAL SEPTIC TANK: YES NO IF YES, CAPACITY _____ GALLONS

LEACH LINES: REPLACED ADDED REPAIRED

TOTAL LINEAR FEET OF LEACH TO BE INSTALLED: _____



PERCOLATION TEST INSTRUCTIONS

An integral part of a properly designed sewage disposal system is the evaluation of soil in which the system will lay.

Percolation tests of the soil determine the acceptability of the site and the design of the subsurface sewage disposal system.

PROCEDURE:

Hand dig three (3) holes in the area designated for the leach field. These holes should have horizontal dimensions of 12 inches and vertical sides to the depth of 30 inches.

A six (6) foot pit should be provided in the center of the three (3) small percolation holes. This hole should be six (6) foot deep and wide enough for observations related to the ground water table and soil profiles.

When the three (3) small holes and six (6) foot pit are completed, call the Health Department at 589-3272 or 589-3278 between 8:30am and 4pm, Monday through Friday. At this time an appointment will be made with a representative of the Environmental Health Division to proceed with the percolation tests.

Fill the three (3) small holes with 5-7 gallons of water 24 hours before the percolation test is to be conducted. DO NOT put water in the six (6) foot hole.

Have 5-7 gallons of water at the site of each small hole the day of the percolation test.

As soon as the soil percolation tests are performed and evaluated, the results will be mailed to you. This procedure generally takes about seven (7) days.

TYPICAL BUILDING LOT

Avoid low, poorly drained areas

